

# How to Use Your Disinfectant Foot Mat

## Set up

- Use appropriate protective clothing for the disinfectant you are using
- Place the black absorbent pad inside the blue waterproof sleeve
- Place the mat where it is to be used on a level surface. This is usually immediately outside the door of the room or area which is to be kept clean.
- Pre-mix the disinfectant to the recommended strength in a bucket or similar container. You will need:  
60 x 90 cm mat: 10 litres per mat  
180 x 90 cm mat: 45 litres per mat
- Pour the disinfectant slowly over the black absorbent pad giving it time to soak in
- Fill the pad until it is saturated and liquid appears when you lightly put your foot on the pad, leave it for 5 minutes and top it up.



Farm and Country Direct  
from  
Intershape

Buy online at [farmandcountrydirect.co.uk](http://farmandcountrydirect.co.uk)

Or call us on 01327 300 395

## Using the Mat

Make sure people entering the premises place both feet firmly on the mat.



## Maintenance

- Top up the mat as necessary by slowly pouring in extra pre-mixed disinfectant if the mat becomes dry. You should always be able to see liquid when you put your foot lightly on the pad.
- If the mat is not used very often and so is not topped up regularly, replenish the disinfectant within its active life (which should be shown on the packaging).
- If the mat gets dirty with mud or other organic matter, clean it by removing the pad from the sleeve and hosing them thoroughly and let them dry. The disinfectant will be less effective if left in a dirty mat.



## After use

- Dispose of contents safely
- Remove black pad from sleeve, hose thoroughly and allow to dry
- Store in a dry area when not in use.